



if hole #1 has OB greater than 50' deep then go half way to alternate portal side and drill again. if still > 50' then go to alternate side and drill pattern

if hole #1 has less than 20' of OB then drill the above pattern as laid out.

if hole #1 has greater than 20' of OB but less than 50' then call Leo!

Just drill for ob depth and go to solid rock

once site selected then drill the five holes along path from that decline

$\left. \begin{array}{l} 30 \times 10 \\ 30 \times 12 \end{array} \right\} \begin{array}{l} \pm 60m \\ 90m \\ 462m \end{array}$   
 $\pm 700m$   
 $770 N$   
 $070 N$